

HG-160

零件價目表

S	滑套	NT.	US.
	Slide Assemble		
S-1	Orange Tip	60	2
S-2	Slide	1100	36.7
S-3	Safety Lever(Right)	80	2.7
S-4	Washer	20	0.8
S-5	Screw	10	0.4
S-6	Pin	10	0.4
S-7	Spring	15	0.5
S-8	Safety Lever(Left)	150	5

B	槍管	NT.	US.
	Barrel Assemble		
B-1	Outer Barrel	300	10
B-2	Inner Barrel	150	5
B-3	Rubber Chamber	50	1.7
B-4	Spacer	30	1
B-5	Short Spring	10	0.4
B-6	Spring	10	0.4
B-7	Barrel Housing (Right)	100	3.3
B-8	Barrel Housing (Left)	100	3.3
B-9	Screw	10	0.4

C	氣室	NT.	US.
	Cylinder Assemble		
C-1	Screw	10	0.4
C-2	Cylinder	150	5
C-3	Spring	20	0.8
C-4	Gas Guide Valve	20	0.8
C-5	Gas Guide Valve Fixer	20	0.8
C-6	Piston Lid	50	1.7

H	擊鎚	NT.	US.
	Hammer Assemble		
H-1	Screw	10	0.4
H-2	Spring	10	0.4
H-3	Hammer Housing (Left)	60	2
H-4-S	Shear (Semi-Auto)	80	2.7
H-4-A	Shear (Full-Auto)	100	3.3
H-5	Impact Hammer Spring	10	0.4
H-6	Hammer Catch	80	2.7
H-7	Impact Hammer	80	2.7
H-8	Pin	60	2
H-9	Spring	10	0.4
H-10	Pin	10	0.4
H-11	Hammer	100	2.7
H-12	Pin	60	2
H-13	Hammer Housing (Right)	60	2
H-14	Hammer Strut	50	1.7
H-15	Hammer Strut Spring	20	0.8
H-16	Spring Housing	50	1.7
H-17	Housing Cover	30	1

CH	氣室座	NT.	US.
	Cylinder Housing Assemble		
CH-1	Cylinder Housing	200	6.7
CH-2	Slide Trajectory	20	0.8
CH-3	Spring	10	0.4
CH-4	Screw	10	0.4

R	覆進簧滑桿	NT.	US.
	Recoil Spring Guide		
R-1	Spring	20	0.8
R-2	Recoil Spring Guide	100	3.3

T	扳機	NT.	US.
	Trigger Assemble		
T-1	Screw	10	0.3
T-2	Trigger Housing (Right)	80	2.7
T-3	Spring	10	0.4
T-4	Shear Catch	20	0.8
T-5	Trigger Spring	10	0.4
T-6	Trigger	100	3.3
T-7	Trigger Housing (Left)	80	2.7
T-8	Screw	10	0.4
T-9	Screw	10	0.4

A	保險活動片	NT.	US.
	Safety Lever Unit (Full-Auto)	120	3.75
A-1-F	Safety Lever Shear		
A-2-F	Safety Lever Spring		
A-3-F	Safety Lever Bar		

A	保險活動片	NT.	US.
	Safety Lever Unit (Semi-Auto)	80	2.7
A-1-S	Safety Lever Shear		

F	槍身	NT.	US.
	Frame Assemble		
F-1	Frame	1500	50
F-2	Trigger Link Rod	80	2.7
F-3	Spring	10	0.4
F-4	Barrel Guide Latch Release	80	2.7
F-5	Barrel Guide Latch	80	2.7
F-6	Spring	10	0.4
F-7	Screw	10	0.4
F-8	Pin	10	0.4
F-9	Magazine Catch Button	80	2.7
F-10	Spring	10	0.4
F-11	Pin	10	0.4
F-12	Ring	10	0.4
F-13	Grip (Right)	80	2.7
F-14	Grip (Left)	80	2.7
F-15	Screw	10	0.4

M	彈匣	NT.	US.
	Magazine		
M-1	Magazine Lid	80	2.7
M-2	Nuzzle Rubber	60	2
M-3	Magazine Case	500	17.7
M-4	Pin	10	0.4
M-5	Pin	10	0.4
M-6	O Ring	20	0.8
M-7	Magazine Base	150	5
M-8	O Ring	20	0.8
M-9	Filling Mouth	50	1.7
M-10	Magazine Follower	60	2
M-11	Magazine Spring	50	1.7

MV	氣閥	NT.	US.
	Magazine Valve		
MV-1	O Ring	20	0.8
MV-2	Magazine Valve (Front)	60	2
MV-3	O Ring	20	0.8
MV-4	Valve Base	100	3.3
MV-5	O Ring	20	0.8
MV-6	Valve Spring	10	0.4
MV-7	□ Shaped Spacer	20	0.8
MV-8	E Shaped Spacer	10	0.4

HG-160

